

ANM001 - MEMS SENSOR PCB DESIGN AND SOLDERING GUIDELINES

SENSORS WITH LGA PACKAGE

Sensor description	Order code
3-axis Acceleration Sensor	2533020201601
Absolute Pressure Sensor	2511020213301
Humidity Sensor	2525020210001

VERSION 1.1

JANUARY 27, 2021

Revision history

App note version	Notes	Date
1.0	 Initial release of the app note 	August 2019
1.1	 Sensor description in the first page updated Chapter 2. PCB Design rules updated 	January 2021

Abbreviations

Abbreviation	Description
GND	Negative supply voltage
l ² C	Inter integrated circuit
LGA	Land grid array
MEMS	Micro-electro-mechanical system
PCB	Printed circuit board
LSB	Least significant bit
VDD	Positive supply voltage


Contents

1	Introduction	4	
2	PCB Design rules		
3	Guidelines for PCB Design	7	
4	Guidelines for soldering4.1Before soldering4.2After soldering	9 9 9	
5	Guidelines for stencil design and solder paste	10	
6	Guidelines for process considerations	10	
7	 Important notes 7.1 General customer responsibility	11 11	
	plications7.3Best care and attention7.4Customer support for product specifications7.5Product improvements7.6Product life cycle7.7Property rights7.8General terms and conditions	11 11 12 12 12 12 12	
8	Legal notice8.1Exclusion of liability	13 13 13 13	
9	License terms for Würth Elektronik eiSos GmbH & Co. KG sensor product software and source code9.1Limited license9.2Usage and obligations9.3Ownership9.4Disclaimer of warranty9.5Limitation of liability9.6Applicable law and jurisdiction9.7Severability clause9.8Miscellaneous	15 15 16 16 16 16 17 17	

1 Introduction

This technical document provides necessary information and general guidelines for soldering and PCB design for the Würth Elektronik eiSos MEMS sensor products with an LGA surface-mount package.

2 PCB Design rules



- 1. Solder mask opening
- 2. PCB land
- 3. Sensor package footprint


Figure 1: PCB land and solder mask recommendations for sensors with LGA package

Dimension	LGA pad spacing > 200 μ m	LGA pad spacing \leq 200 μ m
PCB land width: C	LGA solder pad width + 0.1 mm	LGA solder pad width
PCB land length: D	LGA solder pad length + 0.1 mm	LGA solder pad length

Table 1: PCB land design dimensions

Dimension	Description
Solder mask opening width: A	PCB land length + 0.1 mm
Solder mask opening length: B (when applicable)	PCB land length + 0.1 mm

Table 2: Solder mask opening dimensions





Screw mounting holes, vias and components at a distance greater than 2mm from the sensor is highly recommended to get optimal performance of the sensor




Figure 4: Components inside sensor keep out area




Figure 5: Components outside sensor keep out area

3 Guidelines for PCB Design

- The solder mask opening external to the PCB land is highly recommended. Please refer to figure 1.
- It is recommended to define a keep-out area for the sensor. Any structure underneath the sensor should be avoided.
- The traces connected to the pads should be as symmetrical as possible. Symmetry and balance to the pad connections will help the sensor self-align which leads to better control of solder paste reduction after reflow.
- Screw mounting holes at a distance greater than 2mm from the sensor is highly recommended to get optimal performance of the sensor.
- We recommend to separate digital ground from analog ground in the PCB, if enough space or layer is available. The relatively large, sharp pulses of digital current transitions might affect the precise analog signals if the two signals are not separated.




Figure 6: Asymmetrical trace and sensor pad connections



Information of the PCB design and soldering processes provided in this document is considered for use as a reference.



PCB land design and connecting traces should be designed symmetrically




Figure 7: Symmetrical trace and sensor pad connections



For sensor specific information please refer to corresponding data sheet of the product.

4 Guidelines for soldering

The following soldering guidelines should be taken into consideration for a common PCB design and industrial practices.

4.1 Before soldering

- Routing traces and vias below the sensor should be avoided. The active signals that are routed under may interfere with the MEMS sensor, which will affect the sensor performance.
- It is not necessary to have large traces on VDD/GND line, as the power consumption of the MEMS sensors are very low.
- For best performance of the sensor, design a ground plane under the sensor in order to reduce the PCB signal noise from the board.
- The placement of the MEMS sensor on the PCB should avoid locations in close proximity to heat sources e.g. microprocessors, batteries, graphic controllers etc.
- Push-buttons, screws and PCB anchor points can produce mechanical stress onto the PCB, hence the sensor placement close to these components should be avoided.
- PCB bending will induce mechanical stress to the sensor therewith influence the sensor performance.

4.2 After soldering

- In general, high-amplitude resonant vibrations of the PCB should be avoided. It could possibly damage the MEMS structure.
- The thickness of solder paster must be uniform to reduce the inconsistent stress on the sensor.
- Solder paste must be as thick as possible to reduce the decoupling stress and to avoid the PCB solder mask touching the device package.

5 Guidelines for stencil design and solder paste

For proper mounting process of the MEMS sensor, thickness and soldering paste pattern are very important.

- Stencil thickness of 90 150 μ m (3.5 6 mils) is recommended for screen printing.
- Stainless steel stencils are recommended for solder paste application.
- The signal pad openings of the stencil should be between 70% and 90% of the PCB pad area.
- It is recommended that for better solder paste release, the aperture walls should be trapezoidal and the corners rounded.
- The stencil and printed circuit assembly should be aligned to within 25 μ m (1 mil) before applying the solder paste.

6 Guidelines for process considerations

- To reduce the residual stress on the components, the recommended ramp-down temperature slope should not exceed -3 °C/s.
- LGA packages show metal traces on the side of the package, hence no solder material reflow on the side of the package is allowed.
- The final volume of the solder paste applied to a single PCB land should be less than 20% of the volume of the solder paste of all pads of one device.
- It is not possible to define a specific soldering profile only for the sensors. The soldering profile depends on the number, size and placement of the components in the application board.
- Customer should use a time and temperature reflow profile based on PCB design and manufacturing knowledge.
- No-clean solder paste is recommended for assembly of the MEMS sensor to prevent further cleaning steps.
- Sensor with opening surface on top should be handled carefully. Do not pick the component with vacuum tools which make direct contact with the opening of the sensor.



It is recommended to use a standard pick and place process and equipment. Do not use the hand soldering process.

7 Important notes

The following conditions apply to all goods within the sensors product range of Würth Elektronik eiSos GmbH & Co. KG:

7.1 General customer responsibility

Some goods within the product range of Würth Elektronik eiSos GmbH & Co. KG contain statements regarding general suitability for certain application areas. These statements about suitability are based on our knowledge and experience of typical requirements concerning the areas, serve as general guidance and cannot be estimated as binding statements about the suitability for a customer application. The responsibility for the applicability and use in a particular customer design is always solely within the authority of the customer. Due to this fact, it is up to the customer to evaluate, where appropriate to investigate and to decide whether the device with the specific product characteristics described in the product specification is valid and suitable for the respective customer application or not. Accordingly, the customer is cautioned to verify that the documentation is current before placing orders.

7.2 Customer responsibility related to specific, in particular safety-relevant applications

It has to be clearly pointed out that the possibility of a malfunction of electronic components or failure before the end of the usual lifetime cannot be completely eliminated in the current state of the art, even if the products are operated within the range of the specifications. The same statement is valid for all software and software parts contained in or used with or for products in the sensor product range of Würth Elektronik eiSos GmbH & Co. KG. In certain customer applications requiring a high level of safety and especially in customer applications in which the malfunction or failure of an electronic component could endanger human life or health, it must be ensured by most advanced technological aid of suitable design of the customer application that no injury or damage is caused to third parties in the event of malfunction or failure of an electronic component.

7.3 Best care and attention

Any product-specific data sheets, manuals, application notes, PCN's, warnings and cautions must be strictly observed in the most recent versions and matching to the products revisions. This documents can be downloaded from the product specific sections on the wireless connectivity and sensors homepage.

7.4 Customer support for product specifications

Some products within the product range may contain substances, which are subject to restrictions in certain jurisdictions in order to serve specific technical requirements. Necessary information is available on request. In this case, the field sales engineer or the internal sales person in charge should be contacted who will be happy to support in this matter.

7.5 Product improvements

Due to constant product improvement, product specifications may change from time to time. As a standard reporting procedure of the Product Change Notification (PCN) according to the JEDEC-Standard, we inform about major changes. In case of further queries regarding the PCN, the field sales engineer, the internal sales person or the technical support team in charge should be contacted. The basic responsibility of the customer as per section 7.1 and 7.2 remains unaffected.

The sensor driver software "Sensor SDK" and it's source codes are not subject to the Product Change Notification information process.

7.6 Product life cycle

Due to technical progress and economical evaluation we also reserve the right to discontinue production and delivery of products. As a standard reporting procedure of the Product Termination Notification (PTN) according to the JEDEC-Standard we will inform at an early stage about inevitable product discontinuance. According to this, we cannot ensure that all products within our product range will always be available. Therefore, it needs to be verified with the field sales engineer or the internal sales person in charge about the current product availability expectancy before or when the product for application design-in disposal is considered. The approach named above does not apply in the case of individual agreements deviating from the foregoing for customer-specific products.

7.7 Property rights

All the rights for contractual products produced by Würth Elektronik eiSos GmbH & Co. KG on the basis of ideas, development contracts as well as models or templates that are subject to copyright, patent or commercial protection supplied to the customer will remain with Würth Elektronik eiSos GmbH & Co. KG. Würth Elektronik eiSos GmbH & Co. KG does not warrant or represent that any license, either expressed or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, application, or process in which Würth Elektronik eiSos GmbH & Co. KG components or services are used.

7.8 General terms and conditions

Unless otherwise agreed in individual contracts, all orders are subject to the current version of the "General Terms and Conditions of Würth Elektronik eiSos Group", last version available at *www.we-online.com*.

8 Legal notice

8.1 Exclusion of liability

Würth Elektronik eiSos GmbH & Co. KG considers the information in this document to be correct at the time of publication. However, Würth Elektronik eiSos GmbH & Co. KG reserves the right to modify the information such as technical specifications or functions of its products or discontinue the production of these products or the support of one of these products without any written announcement or notification to customers. The customer must make sure that the information used corresponds to the latest published information. Würth Elektronik eiSos GmbH & Co. KG does not assume any liability for the use of its products. Würth Elektronik eiSos GmbH & Co. KG does not grant licenses for its patent rights or for any other of its intellectual property rights or third-party rights.

Notwithstanding anything above, Würth Elektronik eiSos GmbH & Co. KG makes no representations and/or warranties of any kind for the provided information related to their accuracy, correctness, completeness, usage of the products and/or usability for customer applications. Information published by Würth Elektronik eiSos GmbH & Co. KG regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof.

8.2 Suitability in customer applications

The customer bears the responsibility for compliance of systems or units, in which Würth Elektronik eiSos GmbH & Co. KG products are integrated, with applicable legal regulations. Customer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of Würth Elektronik eiSos GmbH & Co. KG components in its applications, notwithstanding any applications-related in-formation or support that may be provided by Würth Elektronik eiSos GmbH & Co. KG. Customer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences lessen the likelihood of failures that might cause harm and take appropriate remedial actions. The customer will fully indemnify Würth Elektronik eiSos GmbH & Co. KG and its representatives against any damages arising out of the use of any Würth Elektronik eiSos GmbH & Co. KG components in safety-critical applications.

8.3 Usage restriction

Würth Elektronik eiSos GmbH & Co. KG products have been designed and developed for usage in general electronic equipment only. This product is not authorized for use in equipment where a higher safety standard and reliability standard is especially required or where a failure of the product is reasonably expected to cause severe personal injury or death, unless the parties have executed an agreement specifically governing such use. Moreover, Würth Elektronik eiSos GmbH & Co. KG products are neither designed nor intended for use in areas such as military, aerospace, aviation, nuclear control, submarine, transportation (automotive control, train control, ship control), transportation signal, disaster prevention, medical, public information network etc. Würth Elektronik eiSos GmbH & Co. KG must be

informed about the intent of such usage before the design-in stage. In addition, sufficient reliability evaluation checks for safety must be performed on every electronic component, which is used in electrical circuits that require high safety and reliability function or performance. By using Würth Elektronik eiSos GmbH & Co. KG products, the customer agrees to these terms and conditions.

9 License terms for Würth Elektronik eiSos GmbH & Co. KG sensor product software and source code

This License terms will take effect upon the purchase and usage of the Würth Elektronik eiSos GmbH & Co. KG sensor products. You hereby agree that this license terms are applicable to the product and the incorporated software, firmware and source codes (collectively, "Software") made available by Würth Elektronik eiSos in any form, including but not limited to binary, executable or source code form.

The software included in any Würth Elektronik eiSos sensor product is purchased to you on the condition that you accept the terms and conditions of this license terms. You agree to comply with all provisions under this license terms.

9.1 Limited license

Würth Elektronik eiSos hereby grants you a limited, non-exclusive, non-transferable and royalty-free license to use the software and under the conditions that will be set forth in this license terms. You are free to use the provided software only in connection with one of the products from Würth Elektronik eiSos to the extent described in this license terms.

You are entitled to change or alter the source code for the sole purpose of creating an application embedding the Würth Elektronik eiSos sensor product. The transfer of the source code to third parties is allowed to the sole extent that the source code is used by such third parties in connection with our product or another hardware provided by Würth Elektronik eiSos under strict adherence of this license terms. Würth Elektronik eiSos will not assume any liability for the usage of the incorporated software and the source code.

You are not entitled to transfer the source code in any form to third parties without prior written consent of Würth Elektronik eiSos.

You are not allowed to reproduce, translate, reverse engineer, decompile, disassemble or create derivative works of the incorporated software and the source code in whole or in part. No more extensive rights to use and exploit the products are granted to you.

9.2 Usage and obligations

The responsibility for the applicability and use of the Würth Elektronik eiSos sensor product with the incorporated software in a particular customer design is always solely within the authority of the customer. Due to this fact, it is up to you to evaluate and investigate, where appropriate, and to decide whether the device with the specific product characteristics described in the product specification is valid and suitable for your respective application or not.

You are responsible for using the Würth Elektronik eiSos sensor product with the incorporated software in compliance with all applicable product liability and product safety laws. You acknowledge to minimize the risk of loss and harm to individuals and bear the risk for failure leading to personal injury or death due to your usage of the product.

Würth Elektronik eiSos' products are not authorized for use in safety-critical applications, or where a failure of the product is reasonably expected to cause severe personal injury or death. Moreover, Würth Elektronik eiSos' products are neither designed nor intended for

use in areas such as military, aerospace, aviation, nuclear control, submarine, transportation (automotive control, train control, ship control), transportation signal, disaster prevention, medical, public information network etc. You shall inform Würth Elektronik eiSos about the intent of such usage before design-in stage. In certain customer applications requiring a very high level of safety and in which the malfunction or failure of an electronic component could endanger human life or health, you must ensure to have all necessary expertise in the safety and regulatory ramifications of your applications. You acknowledge and agree that you are solely responsible for all legal, regulatory and safety-related requirements concerning your products and any use of Würth Elektronik eiSos' products in such safety-critical applications-related information or support that may be provided by Würth Elektronik eiSos. YOU SHALL INDEMNIFY WÜRTH ELEKTRONIK EISOS AGAINST ANY DAMAGES ARISING OUT OF THE USE OF WÜRTH ELEKTRONIK EISOS' PROD-UCTS IN SUCH SAFETY-CRITICAL APPLICATIONS.

9.3 Ownership

The incorporated Software created by Würth Elektronik eiSos is and will remain the exclusive property of Würth Elektronik eiSos.

9.4 Disclaimer of warranty

THE SOFTWARE AND IT'S SOURCE CODE IS PROVIDED "AS IS". YOU ACKNOWL-EDGE THAT WÜRTH ELEKTRONIK EISOS MAKES NO REPRESENTATIONS AND WAR-RANTIES OF ANY KIND RELATED TO, BUT NOT LIMITED TO THE NON-INFRINGEMENT OF THIRD PARTIES' INTELLECTUAL PROPERTY RIGHTS OR THE MERCHANTABILI-TY OR FITNESS FOR YOUR INTENDED PURPOSE OR USAGE. WÜRTH ELEKTRONIK EISOS DOES NOT WARRANT OR REPRESENT THAT ANY LICENSE, EITHER EXPRESS OR IMPLIED, IS GRANTED UNDER ANY PATENT RIGHT, COPYRIGHT, MASK WORK RIGHT, OR OTHER INTELLECTUAL PROPERTY RIGHT RELATING TO ANY COMBINA-TION, MACHINE, OR PROCESS IN WHICH THE WÜRTH ELEKTRONIK EISOS' PROD-UCT WITH THE INCORPORATED SOFTWARE IS USED. INFORMATION PUBLISHED BY WÜRTH ELEKTRONIK EISOS REGARDING THIRD-PARTY PRODUCTS OR SERVICES DOES NOT CONSTITUTE A LICENSE FROM WÜRTH ELEKTRONIK EISOS TO USE SUCH PRODUCTS OR SERVICES OR A WARRANTY OR ENDORSEMENT THEREOF.

9.5 Limitation of liability

Any liability not expressly provided by Würth Elektronik eiSos shall be disclaimed. You agree to hold us harmless from any third-party claims related to your usage of the Würth Elektronik eiSos' products with the incorporated software and source code. Würth Elektronik eiSos disclaims any liability for any alteration, development created by you or your customers as well as for any combination with other products.

9.6 Applicable law and jurisdiction

Applicable law to this license terms shall be the laws of the Federal Republic of Germany. Any dispute, claim or controversy arising out of or relating to this license terms shall be resolved and finally settled by the court competent for the location of Würth Elektronik eiSos registered office.

9.7 Severability clause

If a provision of this license terms are or becomes invalid, unenforceable or null and void, this shall not affect the remaining provisions of the terms. The parties shall replace any such provisions with new valid provisions that most closely approximate the purpose of the terms.

9.8 Miscellaneous

Würth Elektronik eiSos reserves the right at any time to change this terms at its own discretion. It is your responsibility to check at Würth Elektronik eiSos homepage for any updates. Your continued usage of the products will be deemed as the acceptance of the change. We recommend you to be updated about the status of new software, which is available on our website or in our data sheet, and to implement new software in your device where appropriate.

By ordering a sensor product, you accept this license terms in all terms.

List of Figures


1	PCB land and solder mask recommendations for sensors with LGA package	4
2	Incorrect PCB design	5
3	Correct PCB design	5
4	Components inside sensor keep out area	6
5	Components outside sensor keep out area	6
6	Asymmetrical trace and sensor pad connections	7
7	Symmetrical trace and sensor pad connections	8

List of Tables

1	PCB land design dimensions	4
2	Solder mask opening dimensions	4



more than you expect



Max-Eyth-Straße 1 74638 Waldenburg Germany

Tel.: +49 651 99355-0 Fax.: +49 651 99355-69 www.we-online.com/wireless-connectivity